


# computer operational manual

## main screen



**+** cursor moves

**B** sound on

**A** sound off

**SEL** + **+** / **SEL** + **+** change advance direction (forward, reverse, random)

**B** + **+** tone edit

**B** + **+** return

**B** + **+** tone parameter copy

**B** + **+** tone parameter paste

**A** + **+** laststep on

**A** + **+** laststep off

**A** + **+** / **A** + **+** laststep moves

**A** + **B** + **+** (with laststep on) one line returns to a head

**A** + **B** + **+** (with laststep on) all lines return to a head

**SEL** + **+** (with laststep on) mad laststep on (randomize laststep)

**SEL** + **+** (with laststep on) mad laststep off

**STR** + **+** / **STR** + **+** tempo changes

**SEL** + **STR** stop / **STR** resume

**STR** + **+** load

**STR** + **+** save



| **FREQ** Hz  
 button changes  
 / / / parameter changes  
 randomize parameter ランダム

freq(44Hz-2015Hz)

display by the scale(C3-B8)

oplv

slns

out

### noise

| **nozF1** |  
 button changes  
 / / / parameter changes  
 randomize parameter ランダム

nzp1

nzp2

nzp3

env1

env2

env3

out